



A Phenomenological Study of Contamination Enhanced Laser-Induced Damage in Sealed Lasers

**Dr. Christopher Scurlock, Genesis Engineering Solutions
9811 Greenbelt Road, Lanham, MD 20706
and the
Laser Risk Reduction Program, NASA GSFC**





Space Based Lasers- Earth Sciences



ICESat



ICESat (Ice, Cloud, and land Elevation Satellite) is the benchmark Earth Observing System mission for measuring ice sheet mass balance, cloud and aerosol heights, as well as land topography and vegetation characteristics



Space Based Lasers- Earth Sciences



Carbon 3D


Science Objectives

Landcover Characterization for:

- *Terrestrial ecosystem modeling, monitoring and prediction*
- *Climate modeling and prediction*
- *Global reference data set of topographic spot heights and transects*

Measurement Objectives

- *Vegetation canopy top height ± 1 m*
- *Vertical distribution of intercepted surfaces*
- *Ground Surface elevation ± 1 m*
- *Measurement transects globally gridded to 4 km X 4 km data products*



<http://www.geog.umd.edu/vcl/INSTRUMENT.html>



SOLUTIONS IN SPACE & TECHNOLOGY

Lanham, MD (301.552.0101) Huntsville, AL (256.971.1234)

www.gecllc.com




Space Based Lasers- Planetary Sciences




MOLA

The Mars Orbiter Laser Altimeter, is an instrument on the Mars Global Surveyor spacecraft. It collected altimetry data about the height of surface features on Mars until June 30, 2001.



http://mola.gsfc.nasa.gov/gifs/mola_instrument.jpg



<http://mola.gsfc.nasa.gov/gallery.html>





Space Based Lasers- Planetary Sciences



MLA

Mercury Laser Altimeter:

This instrument contains a laser that will send light to the planet's surface and a sensor that will gather the light after it has been reflected from the surface. Recording variations in this distance will produce highly accurate descriptions of Mercury's topography.






Space Based Lasers- Planetary Sciences



LIBS on the Martian Rover.

A team in Chemistry Division is working with NASA to develop a method of elemental analysis for upcoming space missions.

The LIBS instrument is flexible and can quickly examine a large number of targets in difficult-to-reach locations, such as boulder fields or cliff faces.



<http://pearl1.lanl.gov/external/LIBS/libb.htm>





Space Based Lasers...



- Can produce extraordinary data, unprecedented to date
- Can be used in versatile configurations for a variety of *active* remote sensing applications: Lidar, spectroscopy, etc.
- Are Challenging!





Space Based Lasers- Contamination



Lasers Require Extraordinary Levels of Clean

- **Particulate contaminants on optics**
- **Molecular contaminants on optics**
 - MOLA II is what flew. MOLA I damaged during testing from silicone contamination.
 - GLAS damaged during testing from contaminants in system.
- **Molecular contamination in *atmosphere***





Space Based Lasers- Trace Atmospheric Contaminants



Previous Published Research:

Silicones in sealed system lead to catastrophic damage

Hydrocarbons in sealed system can lead to catastrophic damage...when no O₂ present!

Work done in pure N₂ atmosphere...what about vacuum?

Work done with various hydrocarbons...aromatics worst





Contamination in Sealed Lasers

Experimental Objectives



Objectives

**Test compounds in vacuum systems (also lacking O₂)
look for unexpected onset of damage when exposed
to laser at 1064, 532, 355 (eventually) nm.**

**If positive results (damage occurs) then test the onset
as a function of**


- **Contaminant concentration**
- **Laser Fluence**

**Identify compounds or outgassing products of concern
vs. “safe”.**


Identify mechanism for induced damage.



Experimental Set Up



Experimental Set Up





Experimental Set Up



Test Conditions:

Laser:

1064 nm
180 mJ/pulse (<20 ns pulse)
Beam diameter (at window): 5 mm
Fluence: 680-800 mJ/cm²

System:

Vacuum < 1.0x10⁻³ torr
Contaminant: 5x10⁻³-1.2x10⁻¹ torr
Pump & Hold type Experiment

Substrate(s):

Fused Silica 80/50 Polish
MgF₂ coated

Baseline Conditions:

Fused Silica

- No damage prior to addition of toluene in ≥460K shots
- No damage to sample after system bakeout ≥ 720K shots

MgF₂ Coated

- No damage prior to toluene in ≥460K shots



Results: Toluene

vacuum


Onset of Damage



Sample 13

$P_{\text{tol}}=37\text{mtorr}$
97K shots


Moderate Damage



Sample 20

$P_{\text{tol}}=50\text{mtorr}$
93K shots

Severe Damage



Sample 29

$P_{\text{tol}}=41\text{mtorr}$
124K shots


Perimeter

Center

100x



200x






Results: Toluene

vacuum




Profile of SiO₂ Optic Damage




Results: Toluene

vacuum






Results: Toluene nitrogen



Profile SiO₂ Damage toluene+N₂





Results: Other Materials



Acetone:

**No damage in vacuum (Reported light damage in N₂)
711K shots; Acetone= .14 torr**

NuSil CV 2946:


Heating to 40° C, Effusive source directed toward window

Also to be tested:

IPA, Milbond adhesive, Scotchweld 2216



Possible Mechanism: Toluene



Etc.

$$k_{i(s)} > k_{i(g)}$$





Possible Mechanism: Toluene




Gas Phase Reactions Observed:

Squire and Bernstein, *J. Phys. Chem.* 88 (1984)

Frochtenicht, *J. Phys. Chem.* 102 (1995)

Surface Reaction Observed:

Dabestani and Sigman, Spectroscopy and Photochemical Transformations of Polycyclic Aromatic Hydrocarbons at Silica and Alumina-Air Interfaces." *Solid State and Surface Photochemistry*, V. Ramamurthy and K. Schanze, Eds., Marcel Dekker, (2000) .





Future Work



NuSil CV 2946:

Heating to 40° C, Effusive source directed toward window

Determine relationship of damage to fluence (use higher fluences)

Investigate longer exposure times ($>10^8$)

Use shorter wavelengths

Also to be tested:

IPA, Milbond adhesive, Scotchweld 2216





Acknowledgements



Code 551, Optics Branch, Goddard Space Flight Center

Dr. John Canham, Swales Aerospace

Dr. Floyd Hovis, Fibertek, Inc.

Laser Risk Reduction Program

